

MANDO BLASTER

ASSEMBLY DIAGRAMS









BODY ASSEMBLY

- 1X - MAG PLATE
- 1X - MAG DISK
- 1X - MAG SCREW
- 1X - MAG NUT
- 1X - CLEANING ROD
- 1X - CLEANING ROD END
- 1X - CLEANING ROD CLAMP
- 1X - SLOT GREEBLE
- 1X - POMMEL
- 1X - POMMEL SCREW (8-32 X 7/16)
- 1X - SAFETY
- 2X - SAFETY PIN (3/32 X 3/16)
- 1X - 8-32 X 1/4 LOW HEAD



BREECH ASSEMBLY


BREECH RAIL

BREECH PLATE

BREECH PLATE PIN (3/32 X 3/16)


JMB SCREW LEVER

JMB SCREW



BARREL ASSEMBLY

- 1X) BARREL
- 1X) BARREL COVER
- 1X) BARREL SCREW (10-32 X 1 ½ BUTTONHEAD)
- 1X) FLASH HIDER
- 1X) FLASH HIDER SCREW (10-32 X ½ FLAT HEAD)
- 1X) FRONT SIGHT
- 1X) BARREL BLOCK
- 1X) BARREL BLOCK PIN (1/16 X ¼)
- 2X) BARREL TAB
- 1X) BARREL ROD
- 1X) ROD SCREW (8-32 X 1/8 BUTTON HEAD)



TRIGGER ASSEMBLY

- 1X - TRIGGER
- 1X - KNUCKLE
- 1X - ROCKER
- 1X - HAMMER
- 1X - HAMMER PIN (3/16 X 7/16)
- 1X - FIRING PIN (5/32 X 1/4)
- 3X - ASSEMBLY PIN (3/32 X 7/16)
- 1X - KNUCKLE SPRING (SMALL SPRING)
- 1X - ROCKER SPRING (LARGE SPRING)
- 2X - LEAF SPRING
- 1X - TRIGGER COVER
- 1X - SMALL BUTTON
- 1X - LARGE BUTTON
- 1X - COVER SCREW (8-32 X 1/2 SLOTTED PAN HEAD)

HAMMER PIN

HAMMER

ASSEMBLY PINS

FIRING PIN

KNUCKLE SPRING

ROCKER SPRING

ROCKER

KNUCKLE

TRIGGER

TRIGGER COVER

COVER SCREW

LARGE BUTTON

SMALL BUTTON

LEAF SPRINGS

15

14

14

REAR SIGHT ASSEMBLY

- 11X)SIGHT BODY
- 1X)SIGHT BACK
- 2X) SIGHT BUTTON
- 1X)REAR SIGHT LEAF
- 2X)REAR SIGHT PIN (1/16 X ¼)


SIGHT BACK

REAR SIGHT LEAF

SIGHT BODY

SIGHT BUTTON

REAR SIGHT PINS



GRIPS

